



This striking 22 cubic foot refrigerator comes with the ExtendFresh[™] Temperature Management System and Produce Preserver to help maintain the taste and texture of your freshest food. LED lighting throughout the refrigerator makes food easy to find on every level.

Top Features

ExtendFresh™ Plus Temperature Management System

Produce Preserver

Full-Width Pantry

Manuals & Literature:

Dimension Guide

Installation Guide

Warranty Information

Energy Guide

22 cu.ft. 33-Inch Width Full Depth Non Dispense Bottom Mount Refrigerator

Details

KRBR102ESS

Available Finishes/Colours

Dimensions			
Depth	33 3/4		
Height	70		
Width	32 5/8		
AHAM Volumes And Shelf Area			
Freezer Volume (Cu Ft)	6.45		
Refrigerator Volume (Cu Ft)	15.62		

Configuration and Overview	
Advance Foam Insulation	99.9% lower Global Warming Potential and Better Energy Performance
Counter Depth	No

Details

Advance Foam Insulation

99.9% lower Global Warming Potential and Better Energy Performance

Dotano				
Cooling Type	Single Evaporator			
Counter Depth	No			
Door Style	Flat			
Controls				
Control Type	Electronic			
Air Filter Indicator/Reset	No			
Automatic Defrost	Yes			
Verrouillage des commandes	No			
Door Ajar/Open Alarm	No			
LCD Touch Screen	No			
Control Lockout	No			
Control Location	Interior Up Front			

KitchenAid[®]

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice. Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.

KitchenAid® FOR THE WAY IT'S MADE:

Bottom Mount Refrigerator

PRODUCT MODEL NUMBERS

KBRS19KC	KBRS22KC
INDITION OF THE	INDITOLETICO
KRBR102E	KRBR109E
INITEL INCLE	INIDITIOUE
KRBX102E	KRBX109E
KNDA I UZE	KNDAIU9E

Electrical: A 115-volt, 60-Hz, AC-only, 15- or 20-amp fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your refrigerator be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.


NOTE: Before performing any type of installation, cleaning, or removing a light bulb, turn the control (Thermostat, Refrigerator or Freezer Control depending on the model) to OFF and then disconnect the refrigerator from the electrical source. When you are finished, reconnect the refrigerator to the electrical source and reset the control (Thermostat, Refrigerator or Freezer Control depending on the model) to the desired setting. See "Using the Controls."

Water: A cold water supply with water pressure between 35 and 120 psi (241 and 827 kPa) is required to operate ice maker and water dispenser. If you have questions about your water pressure, call a licensed, qualified plumber.

IMPORTANT: The pressure of the water coming out of a reverse osmosis system going to the water inlet valve of the refrigerator needs to be between 35 and 120 psi (241 and 827 kPa).


Reverse Osmosis Water Supply: If a reverse osmosis water filtration system is connected to your cold water supply, the water pressure to the reverse osmosis system needs to be a minimum of 40 to 60 psi (276 to 414 kPa).

LOCATION REQUIREMENTS



PRODUCT DIMENSIONS

H G cabinet F not incl. handle E incl. handle B top of cabinet



Model Number	Model Size	Heigh - Overall "A"	Height - Top of Cabinet "B"	Depth - Doors Open 90° "C"	Depth - Drawer Open "D"	Depth - With Handles "E"	Depth - Without Handles "F"	Depth - Cabinet Only "G"	Width - Cabinet "H"
KBRS19KC KRBR109E KRBX109E	18.7 cu. ft	67" (170.2 cm)	65½" (166.4 cm)	59" (149.9 cm)	50¾" (128.9 cm)	333⁄8" (84.8 cm)	307⁄8" (78.1 cm)	281⁄8" (71.4 cm)	29¾" (75.6 cm)
KBRS22KC KRBR102E KRBX102E	22.1 cu. ft.	70" (177.8 cm)	68%" (174.9 cm)	62" (157.5 cm)	50¾" (128.9 cm)	33¾" (85.7 cm)	321⁄4" (81.9 cm)	281⁄s" (71.4 cm)	325⁄8" (82.9 cm)

To ensure proper ventilation for your refrigerator, allow for a 1/2" (1.25 cm) space on each side and at the top. Allow at least 1" (2.54 cm) between back of cabinet and the wall. If your refrigerator has an ice maker, allow extra space at the back for the water line connections.

If you are installing your refrigerator next to a fixed wall, leave $21/2^{"}$ (6.3 cm) minimum on the hinge side (some models require more) to allow for the door to swing open.

NOTE: This refrigerator is intended for use in a location where the temperature ranges from a minimum of 55°F (13°C) to a maximum of 110°F (43°C). The preferred room temperature range for optimum performance, which reduces electricity usage and provides superior cooling, is between 60°F (15°C) and 90°F (32°C). It is recommended that you do not install the refrigerator near a heat source, such as an oven or radiator.

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice.