



30-inch Wide French Door Refrigerator - 20 cu. ft.

WRF560SEHB

Available Finishes/Colours

 WRF560SEHZ
FingerPrint Resistant Stainless Steel

Dimensions		Compatibility	
Depth	34 3/8	Connectivity	No
Height	68 3/8	Works With	No
Width	30		

AHAM Volumes And Shelf Area		Details	
Freezer Volume (Cu Ft)	6.34	Advance Foam Insulation	99.9% lower Global Warming Potential and Better Energy Performance
Refrigerator Volume (Cu Ft)	13.34	Cooling Type	Single Evaporator
Total Volume (Cu Ft)	19.7	Counter Depth	No

Configuration and Overview		Misc.	
Advance Foam Insulation	99.9% lower Global Warming Potential and Better Energy Performance	Accessory Relationships	Yes
Counter Depth	No	Home Delivery	Yes
Number of Doors	3	Will Call	Yes

Find purposefully-designed storage zones for items you use most in this 30-inch french door bottom freezer refrigerator. Humidity-controlled crispers let you store fruits and veggies in their ideal environment while adjustable gallon door bins add loading flexibility when and where you need it.

Top Features
Fingerprint Resistant
Tuck Shelf
FreshFlow™ Produce Preserver

Manuals & Literature:

-  [Dimension Guide](#)  [Energy Guide](#)
-  [Owner Manual](#)  [Warranty Information](#)

Exterior	
Base Grille Color	Black

PRODUCT MODEL NUMBERS

WRF560SEH

Electrical: A 115 V, 60 Hz., AC only, 15 or 20 A fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your freezer be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.

NOTE: Before performing any type of installation, cleaning, or removing a light bulb, turn the control (Thermostat, Refrigerator or Freezer Control depending on the model) to OFF and then disconnect the refrigerator from the electrical source. When you are finished, reconnect the refrigerator to the electrical source and reset the control (Thermostat, Refrigerator or Freezer Control depending on the model) to the desired setting. See "Using the Controls."

Water: A cold water supply with water pressure between 35 and 120 psi (241 and 827 kPa) is required to operate the water dispenser and ice maker. If you have questions about your water pressure, call a licensed, qualified plumber.


NOTE: If the water pressure is less than what is required, the flow of water from the water dispenser could decrease or ice cubes could be hollow or irregular shaped.

Reverse Osmosis Water Supply

IMPORTANT: The pressure of the water supply coming out of a reverse osmosis system going to the water inlet valve of the refrigerator needs to be between 35 and 120 psi (241 and 827 kPa).


If a reverse osmosis water filtration system is connected to your home cold water supply, the water pressure to the reverse osmosis system needs to be a minimum of 40 to 60 psi (276 to 414 kPa).

PRODUCT DIMENSIONS



Model Number	Model Size	Height - Overall "A"	Height - Top of Cabinet "B"	Depth - Doors Open 90° "C"	Depth - Drawer Open "D"	Depth - With Handles "E"	Depth - Without Handles "F"	Depth - Cabinet Only "G"	Width - Cabinet "H"
WRF560SEH	20 cu. ft. (566.3 L)	68 ⁵ / ₈ " (173.7 cm)	67 ⁵ / ₈ " (171.1 cm)	51 ⁵ / ₈ " (131.3 cm)	52 ¹ / ₈ " (132.4 cm)	34 ³ / ₈ " (87.3 cm)	32 ³ / ₈ " (82.2 cm)	27 ¹³ / ₁₆ " (70.7 cm)	29 ¹ / ₂ " (74.9 cm)

LOCATION REQUIREMENTS



To ensure proper ventilation for your refrigerator, allow for a 1/2" (1.25 cm) of space on each side and at the top. Allow for a 1" (2.54 cm) space behind the refrigerator. If your refrigerator has an ice maker, allow extra space at the back for the water line connections. When installing your refrigerator next to a fixed wall, leave a 2" (5.08 cm) minimum space between the refrigerator and wall to allow the door to swing open.

NOTE: This refrigerator is intended for use in a location where the temperature ranges from a minimum of 55°F (13°C) to a maximum of 110°F (43°C). The preferred room temperature range for optimum performance, which reduces electricity usage and provides superior cooling, is between 60°F (15°C) and 90°F (32°C). It is recommended that you do not install the refrigerator near a heat source, such as an oven or radiator.